



Installation manual Compleo GO

211510-e 10/2021

Table of contents

1 General information	4
1.1 Introduction	4
1.2 Intended use	4
2 Safety	4
2.1 Safety instructions	4
2.2 Installation and tests	5
2.3 Protective devices	6
2.4 Operator control elements	6
3 Installation	7
3.1 Prerequisites	7
3.2 Scope of supply/Enclosed accessories	7
3.3 Mounting on the wall	7
3.4 Mounting on a column	7
3.5 Electrical connection	7
3.6 Commissioning	8
4 Technical Data	9

1 General information

1.1 Introduction

Thank you for choosing one of our products. The charging stations of Compleo offer convenient, safe and standard compliant charging according to the standard IEC 61851-1, charging mode 3.

Before putting the charging station into operation, read the instruction manual carefully and follow the instructions.

Ensure that all persons working on or using this charging system have read the operating manual, follow the regulations and instructions for working without risk.

Keep the equipment documentation at a location where it is always accessible to the operators of the charging system.

Ensure that no unauthorized persons can access the charging system.

1.2 Intended use

The charging system is intended for use in private and semiprivate areas, e.g. private properties, corporate parking areas, or depots.

Do not use the charging system where explosive or combustible substances (e.g. gases, liquids, or dusts) are stored or are present.

The charging system is intended exclusively for charging electric vehicles.

- Charging in accordance with type 3 of IEC 61851-1
- Plug-and-socket connectors in accordance with IEC 62196
- The charging system is intended for use only in TT, TN-C, and TN-C-S networks. The charging system must not be operated in IT networks.

The charging system is not suitable for charging vehicles with outgassing batteries (e.g. lead-acid batteries).

The charging system is operated as an individual station without a superordinate control system. The charging system is intended exclusively for stationary installation.

The charging system may only be operated and used by persons who have read the operating manual.

The electrical installation, start-up, and maintenance of the charging system may only be performed by qualified electricians who have been correspondingly authorized by the operator.

The qualified electricians must have read and understood the equipment documentation and must comply with its instructions.

Requirements regarding the qualification of electricians:

- Knowledge of and compliance with the 5 safety rules for working with electrical installations:
- - isolate.
- - secure against reactivation.
- - check absence of voltage.
- - ground and short-circuit.
- - cover or block off live parts in the vicinity.

- Reactivation is carried out in reverse order.
- Knowledge of the general and special safety regulations and accident prevention regulations.
- Knowledge of the relevant electrotechnical regulations e.g. checks associated with commissioning and the requirements for operating facilities, rooms, and special types of equipment - power supply for electric vehicles.
- Ability to recognize risks and to avoid potential hazards.

When installing and handling the charging system, the user, the operator, and the electrician must comply with the national regulations on safety and accident prevention.

2 Safety

2.1 Safety instructions

Improper use and non-compliance with the operating manual may jeopardize:

- your life,
- your health,
- charging system and vehicle.

Safety devices on the charging system

- must not be removed,
- must not be manipulated,
- must not be bypassed,
- before each use, it must be checked that the equipment (e.g. housing, connecting line, charging coupler) is undamaged,
- must be repaired or replaced as necessary, in order to preserve the functional properties.

Ensure that:

- safety identifications, e.g. yellow-colored marks,
- danger signs and
- safety lights

remain easily visible and retain their effectiveness.

- When operating the charging system, do not use any extension cables, cable reels, multi-socket power strips, or travel adapters.
- Do not insert any objects into the charging coupler of the charging system.
- Protect the socket-outlets and plug-in connections against moisture and water or other liquids.
- Never immerse the charging system or the charging coupler in water or other liquids.
- Do not disconnect the charging coupler from the vehicle during charging.

Compleo takes responsibility only of the charging system in its delivered condition and for any work performed by skilled Compleo personnel.

Notes for people with a pacemaker (PM) or implantable cardioverter defibrillator (ICD)

Charging systems from Compleo that are operated as intended, comply with the European guideline on electromagnetic compatibility regarding radiated interference.

Should people with a pacemaker (PM) or implantable cardioverter defibrillator (ICD) wish to conduct activities on charging systems and their devices in the intended manner, Compleo is not in a position to make any statement regarding the suitability of such medial devices. Compleo is not able to assess the pacemakers or concerned implantable cardioverter defibrillators with regard to their susceptibility to electromagnetic radiation. This is something that only the manufacturers of the pacemaker or implantable cardioverter defibrillator can do.

Compleo therefore recommends only allowing the people in question to work on its charging systems after consultation with the manufacturer of the pacemaker/defibrillator and the relevant insurance company. Ensure at all times that no health or safety risks are involved.

Note: People with a pacemaker or defibrillator may not work on or stand near the charging systems and their devices, e.g. to perform maintenance operations or rectify any faults.

Working on the charging system without risk:

Before plugging the charging coupler into the vehicle

- The connecting line of the charging system must be completely unwound.
- Check whether the housing of the charging system, the connecting line, the charging coupler, and the connectors are undamaged.
- Take hold of the plug-in connection of the charging system only on the charging coupler and not on the charging cable.
- Ensure that no-one can trip e.g. over the charging cable.

During the charging process

- Keep unauthorized persons away from the charging system.
- When the charging system is connected, you must not clean or wash the vehicle with a high pressure cleaner because the plug-in connection is not sealed against pressurized water.

In case of malfunctions or failure of the charging system

- Disconnect the charging system from the power supply by switching off the respective circuit breaker in the building. Leave a sign with the name of the person authorized to switch on the circuit breaker.
- Call in a qualified electrician immediately.

Electrical devices

- The housing of the charging system must always be kept closed.

2.2 Installation and tests

Information for selecting protective devices for basic and fault protection against touching directly or indirectly

Electrical circuit breakers

The charging system must be protected with circuit breakers in compliance with the respective national regulations. This depends, for example, on the required tripping time, internal network resistance, conductor cross-section, conductor lengths, and the preset rating of the charging system.

The short-circuit protection of the conductor must have a characteristic that permits 8-10-fold of the I_{nom} value and must not exceed a maximum nominal current of 16 A, depending on the preset rating of the charging system.

Residual-current circuit breaker

For reasons of personal safety, national regulations may stipulate an upstream RCD with an $I_{\Delta N}$ of 30 mA AC. Choose a suitable RCD that complies with the national regulations. For this, please refer to the comments in the section DC residual-current detection.

DC residual-current detection

The charging system is equipped with 6 mA DC residual-current detection. The charging system switches itself off if there is a residual current that is greater than or equal to 6 mA DC. Details of this are given in the Diagnostics section.

PE conductor test

After the installation and before switching on for the first time, test the continuity of the PE conductor. For this, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1. Measure the resistance of the PE conductor between the PE conductor socket of the adapter and the connection point of the PE conductor in the building's electrical cabinet. The value of the PE conductor for a total conductor length (connecting line to the charging system and the vehicle charging cable) of up to 5 m must not exceed 300 m Ω . For longer cables, the value can be increased in accordance with the applicable national regulations. In any case, the resistance must not exceed a value of 1 Ω .

Insulation test

Two insulation measurements are required because the charging system is equipped with a disconnecting relay. The charging system must be disconnected from the power supply for this. Therefore, before the measurement, switch off the supply voltage using the circuit breaker in the building's electrical cabinet.

1. Measurement of the primary side of the charging system.

Measure the insulation resistance on the primary side of the charging system at the connection point of the power supply line to the charging system in the building's electrical cabinet. The value must not exceed 1 M Ω .

Note: The Wallbox has a surge protector. This may be considered in the course of making measurements.

2. Measurement of the secondary side of the charging system.

For this, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1.

Measure the insulation via the measuring sockets on the test adapter. The value must not exceed 1 M Ω .

Alternatively, the differential current method can be used in conjunction with measurement of the PE conductor current. In both cases, the value must not exceed 3.5 mA.

For these measurements, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1. The measurements must be carried out with the adapter in the C mode. Measure

the differential current at the connection point of the power supply line to the charging system in the building's electrical cabinet.

- **Test of the power-off condition in case of a shortcircuit (ZL-N)**

For these measurements, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1. The measurements must be carried out with the adapter in the C mode. Carry out the measurements on the measuring sockets of the test adapter. The values must comply with those of the selected circuit breaker.

- **Test of the power-off condition in case of a fault (ZL-PE)**

For these measurements, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1. The measurements must be carried out with the adapter in the C mode. Carry out the measurements on the measuring sockets of the test adapter with a suitable instrument. The values must comply with those of the selected circuit breaker.

- **Test of the integrated DC residual-current detection**

For these measurements, connect the charging coupler to a test adapter for vehicle simulation in accordance with EN 61581-1. The measurements must be carried out with the adapter in the C mode. Carry out the measurements on the measuring sockets of the test adapter with a suitable instrument. If the residual

current is greater than 6 mA DC, the charging system must disconnect the charging coupler from the power supply. The fault indicator on the charging system must be activated.

- **Test of the upstream RCD**

The upstream RCD must be tested at the connection point of the power supply line to the charging system in the building's electrical cabinet. The RCD must trip in accordance with the national regulations.

2.3 Protective devices

The following components are protective devices:



Figure 1: Charging system

- 1** Housing
- 2** Charging cable
- 3** Protective cover
- 4** Charging coupler

Checking the protective devices:

1. Before every charging process, make a visual inspection of the protective devices for damage.
2. Have a qualified electrician make regular electrical function tests in accordance with the national regulations.

2.4 Operator control elements

The following figure shows the Compleo GO charging station. Depending on the variant ordered, the optical appearance differs from the figure.



Figure 2: Overview of Compleo GO

- 1** Pushbutton/LED combination
- 2** Nameplate

The charging system can be operated with a single button/LED combination (Fig. 2). An optional external blocking device (e.g. key switch) can be connected to the internal interface.

Functions of the LED

The LED indicates the operating state of the charging system. Detailed information on the operating states is given in the operating manual.

Functions of the button

The functions of the button are described in the operating manual.

Starting the charging process

The charging process starts automatically as soon as the charging coupler is plugged in and the vehicle requests a charging process.

Stopping the charging process

Note: The charging process cannot be stopped with the button. There are 3 ways of stopping the charging process.

Stop the charging process with the operating controls in the vehicle. Instructions on this are given in the vehicle's operating manual.

or

Disconnect the charging system from the power supply by switching off the respective circuit breaker in the building.

or

Disable the charging system using the optional external blocking device.

Optional external blocking device

If an external blocking device (e.g. key switch) is connected, the charging process is only started

when the Wallbox has been enabled by the external blocking device.

3 Installation

3.1 Prerequisites

- The Wallbox may only be operated when mounted vertically.
- If possible, the Wallbox should be mounted so that it is not directly exposed to rain e.g. to prevent icing, being damaged by hail or similar. Do not expose the Wallbox to direct sunlight because this can cause it to overheat.
- The individual phases of the supply voltage must each be protected with residual current devices and circuit breakers.
- No single wires may be used for power supply.
- The diameter of the supply line must be between 9 mm and 17 mm.
- The charging current of the Wallbox must be set in accordance with the building's circuit breakers. (The procedure is described in the „Electrical connection“ section.)

3.2 Scope of supply/Enclosed accessories

- Mounting plate with electronics housing,
- Wallbox housing cover,
- 4x fillister head screws M4x10 (to attach the housing cover of the Wallbox),
- Cable gland ESKV25 (cable entry for power supply),
- Gasket EADR25, for cable gland ESKV25,
- Device documentation (safety instructions, installation instructions, operating manual).

3.3 Mounting on the wall

Disconnect the charging system from the power supply by switching off the respective circuit breaker in the building.



Figure 3: Overview of Compleo GO

Prerequisites

Recommended mounting height above the floor is 1.00 m -1.10 m up to the lower hole.

The mounted Wallbox must be able to withstand a load of at least 16 kg.

Installation steps

1. Mark the three mounting holes (Fig. 3) as shown on the drilling plan.
2. Drill and prepare the mounting holes according to the type of mounting surface (e.g. dowels for masonry). The screw diameter must not exceed 8 mm.

3. Screw in the two top fastening screws.

Note: The fastening screws are not included in the scope of delivery due to the different types of mounting surfaces.

4. Hang the mounting plate (Fig. 4) of the Wallbox on the two fastening screws (slotted holes, Fig. 4).
5. Screw the third fastening screw into the lower hole.
6. Tighten the three fastening screws (approx.12 Nm).

3.4 Mounting on a column

1. Hang the mounting plate of the Wallbox (Fig. 4) on the three stud bolts of the column.
2. Screw the three nuts (separate parts set for the column) on the stud bolts and tighten (approx. 12 Nm).

3.5 Electrical connection




Figure 4: Compleo GO, opened electronics housing

Prerequisites

The Wallbox can be connected with a single phase 1 AC 230 V or with three phases 3 AC 400 V.

1. Remove the four screws (Fig. 4/1) and take off the cover of the electronics housing (Fig. 4/2).
2. Screw the cable gland ESKV25 (enclosed accessories) with the respective gasket EADR25 (enclosed accessories) into the electronics housing (Fig. 4/3) and tighten (approx. 8 Nm).
3. Strip off maximum 13 cm jacket from the power supply cable.

- Strip off approx. 11 to 13 mm insulation from the individual wires.
- Follow the instructions on the sticker (Fig. 4/4) and then pierce the sticker on the cable entry.
- Insert the connecting line into the cable gland.
- Tighten the cap nuts of the cable gland (approx. 4 Nm).




Figure 5: Terminal clamps of the power supply unit

Caution - Heed the terminal sequence. When clamping the connecting line, heed the sequence of the terminals. PE, L3, L2, L1, N.

Reverse polarity of the electrical connecting lines will destroy the electronics in the Wallbox!

- Connect the individual wires of the power supply cable as shown in the diagram (Fig. 5). If a singlephase supply voltage is used, it must be connected to L1. Terminals L2 and L3 are not used for a single-phase connection.

Note: This is a tool-free terminal strip. Folding back the clamping lever (Fig. 5/1) opens the terminal so that the respective individual wire can be inserted. The respective clamping lever is then shut to secure the respective individual wire. Folding back more than one clamping lever at a time must be avoided.




Figure 6: Opened electronics housing

Setting the charging current

The charging current of the Wallbox must be set in accordance with the building's circuit breakers. Under no circumstances may the charging current

be set higher than the respective circuit breaker.

The rotary switch (Fig. 6/1) is used to set the charging current from 6 to 16 A.

0	6 A (default setting, delivery state)
1	8 A
2	10 A
3	12 A
4	14 A
5 ... 9	16 A

External enabling/disabling of the Wallbox

- The Wallbox can be optionally disabled or enabled by means of external switching elements (e.g. key switch). For this, the plug (Fig. 6/2) in the electronics housing must be pulled out and the wire jumper removed.
- The now vacant contacts of the plug must then be connected to a two-pole lead that exits through the cable entry (Fig. 6/3) to the corresponding switching element.
- The contacts of the switching element must be dimensioned so that they can switch zero-potential currents of approx. 30 mA/12 V.
- Replace the lid of the electronics housing (Fig. 4/2) and tighten the four screws (2.5 Nm).
- Replace the cover, fasten it with the four screws M4x10 and tighten them (1.8 Nm). The four screws are included in the enclosed accessories.

3.6 Commissioning



Figure 7: Compleo GO

- Pushbutton/LED combination

- Nameplate

- Provide power to the Wallbox.

Once the Wallbox is connected to the mains, the LED lights up green.

After approx. 12 min in the ready mode without being connected to a vehicle, the Wallbox changes into the standby mode and the LED goes out.

Wake up option 1:

- When the charging cable is plugged into the ve-

hicle while the Wallbox is in the standby mode, it automatically switches to the ready mode. The LED lights up green.

Wake up option 2:

- When the button is pressed (without connected vehicle), the Wallbox changes from the standby mode to the ready mode. The LED lights up green and the charging cable can now be plugged into the vehicle.

As soon as the vehicle requests a charging process, the Wallbox enables the charging process and the LED blinks green.

Note: If an external blocking device is used, when the vehicle is connected, it checks whether there is an external block (e.g. by means of a key switch or similar). As long as the external device has not enabled the Wallbox, the LED lights up yellow and no charging takes place. After the external device has enabled the Wallbox, the LED lights up green.

Note: The procedure in case of a malfunction (LED lights up/blinks yellow or red) is described in the operating manual of the Wallbox.

Operating temperature	-25°C to 40°C 
Protection class	I
Protection degree	IP54
Rated voltage U_n	230V / 400V 1/3 AC
Rated current I_n	up to 16 A adjustable from 6 A to 16 A in 2 A steps
Nominal frequency f_n	50 Hz
Overvoltage categor	III
System according to type of earth connection	TN
Installation site	private, semi-public
EMC classification	EN 61000-6-2, EN 61000-6-3

4 Technical data

Power class 11 kW

Construction type Wallbox or charging column

Number of charging points 1

Charging capacity per charging point 11 kW

Voltage 230 / 400 V

Amperage 16 A

Phases 1-3 Phases

Authorization Plug & Charge

Charging socket No

Charging cable Type 2, firmly attached, 5 m

Dimensions wallbox (H x W x D) 386 x 295 x 117 mm

Weight wallbox 8 kg

Dimensions charging column (H x W x D) 1370 x 250 x 180 mm

Weight charging column 11,5 kg

Load contactor Relay

Control fuse No

Integrated fuses Residual current detection, AC 30 mA, DC 6 mA

RCD (required in sub-distribution) FI Type A

Circuit breaker (required in sub-distribution) max C 16A

DC tripping current $I_{\Delta dc}$ 0,006 A

Housing lockable No

Energy meter No

Adjustable No

Storage temperature -25°C to 40°C 

©2021 Compleo. All rights reserved.

This document may not be copied or reproduced in any form or by any means, in whole or in part, without written permission. All illustrations in these assembly instructions serve only as examples and may differ from the delivered product. All information in this manual is subject to change without notice and does not represent a commitment on the part of the manufacturer.



Contact

Compleo Connect GmbH
Paderborner Straße 76
D-33189 Schlangen

T: +49 5252 9889220
info@compleo-cs.com
www.compleo-cs.com

Technical changes and errors are reserved.
Ver. 20210709